



SAFETY INSTRUCTIONS



- Before starting to work on the device, disconnect the power supply.
All work on live parts must be carried out in accordance with the relevant national law and installation regulations. (e.g. VDE 0100, -ÖVE-EN1, -SEV 1000)



- Do not look directly into the light source. Your eyes could be harmed.



- When changing the LED light, the electrical supply line must be disconnected from the power supply.

Turn off the power supply / unplug the power cord and check the absence of voltage with a voltage tester.



- Allow the LED light to cool completely before changing the bulb.



- Do not touch the outer ring of the LED light, it can get very hot.

- Permitted light sources:

Power: **max. 7 W** (LED no incandescent lamp, no energy-saving lamp allowed)

Voltage: **230/240 V, 50/60 Hz**

Further data regarding the used LED lamp can be seen on the supplied packaging.



- After the change, please dispose of the defective LED source correctly according to local regulations.

Schill GmbH & Co.KG

D-70734 Fellbach

Bruckstr. 44

Tel. 0711 / 57 88 07-0

Fax 0711 / 57 88 07-44

e-mail: info@schill.de

www.schill.de